

# ***Application of Reflective Reboundable Workzone Sheeting***

Instructional Bulletin # 8.03

Issued: 06/27/01

## ***Storage and Conditioning***

Avery Dennison Reflective Sheeting should be used within one year of date of purchase. All guarantees and warranties, expressed or implied, shall become null and void in all respects on materials stored prior to application for periods in excess of one year.

It is recommended that Avery Dennison Reflective Sheeting be stored in a cool, dry environment; preferably at 65°-75°F (18.3°-29.7°C) and 45%-55% relative humidity. If materials are stored in areas separated from the application or converting area, it is advisable to allow the material to acclimate to the application or converting area prior to use.

## ***Application***

The HDPE and LDPE surface needs to be clean, dry and thoroughly flame treated prior to applying WR-6100 Reboundable Sheeting. Care needs to be taken to apply enough heat to remove any surface residue but not so much heat that the drum surface is distorted. If the drum surface is not flame treated, outgassing can occur over time resulting in puckers or bubbles in the reflective sheeting from trapped air. If puckers or bubbles occur, they can be removed by puncturing the area with a pin and using squeegee or hand pressure to press the sheeting onto the drum surface.

The Drum surface needs to be 60°F (16°C) or warmer for maximum adhesion build. The WR-6100 can be repositioned during the installation process but within 2-3 minutes it will become difficult to remove without distorting the sheeting. After 24 hours the adhesive builds to its ultimate permanent bond.

When applied by hand, WR-6100 needs to have tension on the material maintained as the drum is rotated to minimize air entrapment. If using a hard nylon squeegee, the applicator must be careful not to scratch the sheeting surface. A soft rag can be put over the squeegee to prevent scuffing the surface of the sheeting.

When applying the WR-6100 product, the 4 or 6 inch stripes need to be applied around the circumference of the drum and overlap on itself a minimum of 1 inch.

## ***Storage of Drums after installation***

Make sure to mark drums with the appropriate manufacturing information so the drums may be tracked at a later date.

Allow drums to set 24 hours at 60°F or greater so that the adhesive can build to a permanent level before putting the drums into use as a reboundable workzone device.

### ***Cleaning Of Reboundable Drums***

The cleaning solution in a pH range of 4 to 10 (within mild acid or mild alkaline limits) is recommended. Use a mild soap or a cleaning solution along with warm water and a soft cloth or sponge. A non-abrasive cleaning solution, free of strong solvents, can also be used. If it becomes necessary to remove heavy soil and grease, kerosene, mineral spirits, heptane, or V.M. & P naphtha may be used. Avoid all other solvents.

Test the cleaner on a small section or sample of the material before use. Do not use high pressure sprays.

Spray or wipe (with a soft cloth or sponge) the cleaning solution over the entire surface of the film to be cleaned (avoid abrading the film surface with unnecessary scrubbing); thoroughly agitate and mix the cleaning solution into the dirt on the film's surface; rinse the entire surface with clean water and let air dry.

*NOTE: The above recommendations and cleaners are intended as a source of information and are given without a guarantee and do not constitute a warranty. Purchasers should independently test cleaning agents and methods, prior to use, to determine their suitability.*

Avery Dennison, 6565 W. Howard, Niles, IL 60714, USA, 1-800-327-5917, [www.reflectives.averydennison.com](http://www.reflectives.averydennison.com)